


No Scale

Notes :

- 1. When the Strainer Elevation is lower than the Coil the Hose End Drain Valve at the coil csan be deleted.
- 2. See Valve and Fitting Installation Detail for Additional Requirements





Notes :

- 1. When the Strainer Elevation is lower than the Coil the Hose End Drain Valve at the coil csan be deleted.
- 2. See Valve and Fitting Installation Detail for Additional Requirements
- 3. Use Valve as a Balancing Valve with a Memory Stop.